

My laptop camera is not working? How do I get it to work?

The most common cause of laptop camera's not displaying is that the camera is blocked by the camera privacy shutter. The privacy shutter is hard to see, but it's just above the camera in the middle of the top of the laptop.

This YouTube video shows where the privacy shutter is located:

<https://www.youtube.com/watch?v=G9x7P5njCmQ>

If the privacy shutter on your laptop is open and the camera still does not display, contact PHS IT at ithelp@phmail.ucdavis.edu

Revision #1

Created 30 October 2024 20:03:10 by Cornel Wade

Updated 30 October 2024 20:06:34 by Cornel Wade